


Lawson Hydraulic System- Front View 42," 47" , 52"



| Key No. | Part No. | Description | Qty. |
|---------|----------|----------------|------|
| 1 | 5AC2298 | Pressure Gauge | 1 |
| 2 | 5BA2071 | Spacer | 1 |
| 3 | 6104 | Snubber | 1 |
| 4 | 6140 | Bushing | 1 |
| 5 | 6143 | Connector | 1 |
| 6 | 3297 | Tubing | AR |
| 7 | 2532 | Shut-off Valve | 1 |
| 8 | 5BC2012 | Fitting | 1 |
| 9 | 7771 | Elbow | 1 |
| 10 | 7777 | Hose Assembly | 1 |
| 11 | 852 | Screw | 4 |
| 12 | 5BB2320 | Bracket | 1 |
| 13 | 5BB2321 | Plunger | 1 |
| 14 | 223 | Screw | 4 |
| 15 | 7792 | Four Way Valve | 1 |
| 15A | 6666 | Solenoid | 1 |
| 16 | 6867 | Connector | 2 |
| 17 | 6873 | Tubing | AR |
| 18 | 7719 | Check Valve | 1 |
| 19 | 7369 | Elbow | 1 |
| 20 | 6863 | Nipple | 1 |

| Key No. | Part No. | Description | Qty. |
|---------|----------|-----------------|------|
| 21 | 5BA2075 | Locknut | 1 |
| 22 | 1251 | Screw | 4 |
| 23 | 6084 | Valve | 1 |
| 24 | 4530 | Screw | 4 |
| 25 | 5762 | Valve | 1 |
| 26 | 5BA2074 | Housing | 1 |
| 27 | 6107 | Seal Washer | 1 |
| 28 | 0BA2004 | Spring | 1 |
| 29 | 3677 | Ball | 1 |
| 30 | 2696 | Switch | 1 |
| 31 | 100 | Screw | 4 |
| 32 | 5BA2076 | Bracket | 1 |
| 33 | 5BA2079 | Switch Assembly | 1 |
| 34 | 3505 | Plug | 1 |
| 35 | 222 | Screw | 4 |
| 36 | 220 | Screw | 2 |
| 37 | 5BB6005 | Subplate | 1 |
| 38 | 5BA2068 | Gasket | 1 |
| 39 | 223 | Screw | 4 |
| 40 | 5BA4013 | Support | 1 |
| 41 | 5BA2084 | Gasket | 1 |

Jallo Equipment & Supply, Inc.
2030 West Parkes Drive
Broadview, IL 60155


P: 708-410-1780

www.jallo.com e-mail: jallo@ais.net

F: 708-410-1790

Lawson Hydraulic System- Rear View

42", 47", 52"



| Key No. | Part No. | Description | Qty. |
|---------|----------|-------------------|------|
| 1 | 7620 | Nipple | 1 |
| 2 | 7621 | Elbow | 1 |
| 3 | 7775 | Hose Assembly | 1 |
| 3 | 7774 | Hose Assembly | 1 |
| 4 | 101 | Screw | 8 |
| 5 | 5BC2010 | Adapter | 1 |
| 6 | 1BE2002 | Gasket | 1 |
| 7 | 3801 | Filter | 1 |
| 8 | 8909 | Elbow | 1 |
| 9 | 7776 | Hose Assembly | 1 |
| 10 | 5BC2012 | Bulk Head Fitting | 1 |
| 11 | 5BA4012 | Vent Valve | 1 |
| 12 | 5BA2095 | Screw | 2 |
| 13 | 5BA2116 | Spacer | 2 |
| 14 | 502CP | Setscrew | 1 |
| 15 | 5BA4014 | Manifold | 1 |
| 16 | 6110 | O-Ring | 1 |
| 17 | 6542 | Connector | 1 |
| 18 | 7768 | Tubing | AR |
| 19 | 1936 | Elbow | 2 |
| 20 | 923 | Nut | 2 |
| 21 | 202 | Screw | 4 |
| 22 | 3333 | Relief Valve | 1 |
| 23 | 5BA2086 | Dump Pipe | 1 |
| 24 | 6156 | Elbow | 2 |
| 25 | 6158 | Nipple | 1 |
| 26 | 6157 | Nipple | 1 |
| 27 | 5BA2085 | Dump Pipe | 1 |
| 28 | 6156 | Elbow | 2 |
| 29 | 3870 | Nipple | 1 |

| Key No. | Part No. | Description | Qty. |
|---------|----------|--------------------|------|
| 30 | 6158 | Nipple | 1 |
| 31 | 5310 | Connector | 1 |
| 32 | 6873 | Tubing | AR |
| 33 | 6872 | Flow Control | 1 |
| 34 | 6863 | Nipple | 1 |
| 35 | 6865 | Bushing | 1 |
| 36 | 5310 | Connector | 1 |
| 37 | 6864 | Check Valve | 1 |
| 38 | 6863 | Nipple | 1 |
| 39 | 5295 | Bushing | 1 |
| 40 | 6116 | Hose Assembly | 1 |
| 40 | 6569 | Hose Assembly | 1 |
| 41 | 5384 | Elbow | 1 |
| 42 | 6109 | Fitting | 1 |
| 43 | 6617 | Elbow | 1 |
| 44 | 6862 | Tee | 1 |
| 45 | 7620 | Nipple | 1 |
| 46 | 3970 | Plug | 1 |
| 47 | 6115 | Hose Assembly | 1 |
| 47 | 5389 | Hose Assembly | 1 |
| 48 | 6114 | Elbow | 1 |
| 49 | 3539 | Flow Control | 1 |
| 50 | 5387 | Nipple | 1 |
| 51 | 5386 | Bushing | 1 |
| 52 | 223 | Screw | 4 |
| 53 | 5BA4062 | Valve | 1 |
| 54 | 5BG2006 | Pin | 1 |
| 55 | 2488 | O-Ring | 1 |
| 56 | 5BG5003 | Cylinder 47" & 52" | 1 |
| 56 | 5BA6052 | Cylinder 42" | 1 |

Jallo Equipment & Supply, Inc.
 2030 W. Parkes Dr. * Broadview, IL 60155

P: 708-410-1780

www.jallo.com * jallo@ais.net

F: 708-410-1790